


# HOARD **FAST**

smarter site segregation



 Robust PVC

 Smart Finish

 Relocatable

 Rapid Install

 No Fixings

 Space Saving



**Hoardfast is a division of Protecta Group**

Ph: 09 526 1943 | Fax: 09 580 1402

13 Olive Road, Penrose, Auckland 1061.

See over for installation instructions

## Demountable PVC Hoarding System - Installation Instructions



### Step 1

Slide on an HF PVC HD-Joiner Section over the Support Post. In the case of a lower than 3.5m high ceiling tilt the Support Post to prevent the HD-Joiner from touching the ceiling.



### Step 2

Fit a HF Yellow Base Weight to the HF Base Plate/Support Post and tighten the connecting bolt as shown.



### Step 3

Place a cut to size HF PVC Channel (1134mm long approx) on the floor against the outside edge of the HD Joiner.

Slide an HF PVC Panel into the floor channel and into the HD-Joiner.

Ensure that the edge of the panel is located over the locating lug (which is part of the Base Plate/Support Post).

Continue to fit additional panels repeating steps 1 & 2 ensuring that every panel has an, HD-Joiner, Base Plate/Support Post and Yellow Base Weight.



### Step 4

Fit top HF PVC Channel as shown and use a soft rubber mallet if required to fit neatly against the top of HD-Joiners.

Join top channels together continuously using machine ends where possible to ensure joiners are well presented. Joins should be located above HD-Joiners.

### ADDITIONAL INSTALLATION RECOMMENDATIONS

- Trim bottom channels to ensure they fit neatly against outside edges of HD-Joiners.
- Ensure bottom channels are pressed down tight to the floor.
- Connect the first and final panels to Wall Starter (PVC Channel)
- Fix Starter to wall with screws or double sided tape if appropriate. If fixing is not permitted use a post with weight & HD-Joiner as an alternative starting and finishing connection.
- Panels and tracking should all connect without any tools but at times a soft rubber mallet may be used to assist with assembly.
- Fit additional Yellow Base Weights where extra stability may be required or beside a door frame. (Please contact Hoardfast regarding door and frame fitting information).
- When installing panels around a corner use the PVC Corner Section which is fitted from the floor to the top of the Top Channel.